



## CQ TERMINATOR ASSEMBLY

The Terminator is required in order to have full functionality of the RC5 remote control module when used with a CQ Series power sequencer. This RJ45 plug device needs to be inserted in the last output connector of the last CQ device in a power sequencing network.

One Terminator is included in the box with every RC5 Series product. If the Terminator is lost or damaged, a replacement unit can be easily created.

Use a section of flat, eight wire RJ45 cable long enough to have 1" to 2" extending from RJ45 connector after being inserted and crimped. Crimp one end firmly into a RJ45 connector. Strip the outer insulation from the other end of the cable. Strip the remaining insulation from the middle two conductors. Twist those together. Clip all other conductors shorter to prevent accidental short circuit. Secure that end of the cable with electrical tape or heat shrink insulation if available.